


JUMPERS

THE JUMPER FROM RTD SENSE TO RTD RETURN ELIMINATES THE NEED FOR A THIRD WIRE, BUT IT ALSO DEFEATS THE AUTOMATIC COMPENSATION FOR LEAD RESISTANCE. FOR LENGTHS OVER 15 FEET, THE JUMPER SHOULD BE OMITTED AND A THIRD WIRE USED.

THE JUMPER FROM SOLUTION GROUND TO REFERENCE WILL MAKE THE SENSOR DIAGNOSTICS RETURN ZERO FOR REFERENCE CELL RESISTANCE. THIS CAN BE DISABLED IN SOFTWARE IF DESIRED.

SHIELDING

TAKE CARE NOT TO ALLOW THE BNC SHIELD (REFERENCE LEAD) TO CONTACT METAL PIPING OR J-BOXES AT ANY POINT, AS THIS WILL SHORT THE REFERENCE CELL TO EARTH GROUND, AND CAUSE UNSTABLE READINGS. SHIELDING OF THE CABLE FROM PREAMPLIFIER TO INSTRUMENT IS OPTIONAL.

		11751 Markon Drive	
		Garden Grove, CA. 92841 USA	
DRAWN BOB HUNT		TITLE	
CHECKED 1/18/02		SDI LOW POWER PREAMPLIFIER WITH UNILOC 1055/Solu Comp II	
APPROVED	SCALE NONE	DRAWING NO.	REV.
	SHEET 1 OF 1	SDI-1055	

phone: 714-895-4344 fax: 714-894-4839