

**NOTES :**

**GENERAL**

OUTPUT TO THE INSTRUMENT FROM THE PREAMP IS A GAIN OF +6.03, NORMAL POLARITY.

WHEN A COMBINATION ELECTRODE IS USED, REFERENCE CONNECTION IS MADE THROUGH THE BNC CONNECTOR.

IF A SEPARATE REFERENCE CELL IS USED, CONNECT IT TO THE YELLOW LEAD, AND LEAVE THE CONNECTION TO S4 IN PLACE.


**TEMPERATURE COMPENSATION**

THE PREAMPLIFIER PERFORMS AUTOMATIC COMPENSATION USING A 3KΩ AT 25°C BALCO ELEMENT, WITH A SLOPE OF +13.5Ω/°C. IF YOU ARE NOT USING A BALCO ELEMENT, THEN A 3.01KΩ RESISTOR MUST BE CONNECTED BETWEEN THE RED AND YELLOW LEADS.

**SHIELDING**

TAKE CARE NOT TO ALLOW THE BNC SHIELD (REFERENCE LEAD) TO CONTACT METAL PIPING OR J-BOXES AT ANY POINT, AS THIS WILL SHORT THE REFERENCE CELL TO EARTH GROUND, AND CAUSE UNSTABLE READINGS. SHIELDING OF THE CABLE FROM AMPLIFIER TO INSTRUMENT IS USUALLY NOT REQUIRED. IF A SHIELD IS USED, CONNECT IT TO REFERENCE AT ONE POINT ONLY, AND BE SURE THAT IT DOES NOT TOUCH ANY OF THE OTHER LEADS.

NOTES UNLESS OTHERWISE SPECIFIED:

		11751 Markon Drive	
		Garden Grove, CA. 92841 USA	
		phone: 714-895-4344 fax: 714-894-4839	
DRAWN	<b>BOB HUNT</b>	TITLE	
CHECKED		<b>U2587 PREAMPLIFIER WITH UNILOC 1050</b>	
APPROVED		SCALE	<b>NONE</b>
		DRAWING NO.	REV.
		SHEET	<b>1 OF 1</b>
		<b>U2587-1050</b>	